



REMOVAL AND INSTALLATION

Special Tools:

[Click here to launch the form to order any tools you need.](#)

	<p>10118 - Installer, Input Shaft Seal Originally Shipped In Kit Number(s) 10100, 10100.</p>
	<p>C-4171 - Driver Handle, Universal Originally Shipped In Kit Number(s) 9202, 9202A-CAN, 9202CC, 9299, 9299CC, 9299CC, 9300A-CAN.</p>

REMOVAL

1. Remove the transfer case from the vehicle (Refer to 21 - Transmission and Transfer Case/Transfer Case/Removal and Installation).
2. Using a suitable pry tool or a screw mounted in a slide hammer, remove the input shaft seal.

INSTALLATION

NOTE: Lubricate all seals with MOPAR® ATF+4 prior to installation.

1. Using **10118** (1) and **C-4171** , install the **NEW** front input shaft seal.
2. Install the transfer case in the vehicle (Refer to 21 - Transmission and Transfer Case/Transfer Case/Removal and Installation).

