

Vehicle: 2020 JEEP GLADIATOR: RUBICON 3.6L V6 (G) ERC-GAS-FI-N

Content: Body & Frame

PICK-UP BOX

REMOVAL

1. Disconnect and isolate battery ground cable(s).
2. Disconnect fuel filler neck from fuel tank.
3. Disconnect tail lamp wire harness from underbody wire harness.
4. If required, remove tail lamp units and wire harness from cargo box.
5. If required, remove tailgate as outlined in [Tailgate](#).
6. If required, remove rear bumper as outlined in [Rear Bumper](#).
7. Using an induction heating type tool, or equivalent, heat up each bolt (2) to soften thread locking compound on bolt threads, **Fig. 1**. **Caution: Do not use power tools to remove or install fastener(s). If power tools are used, damage to vehicle or components may occur.**
8. Remove and discard bolts (2) that secure cargo box (1) to frame and remove cargo box, **Fig. 1**.

INSTALLATION

1. Position cargo box onto frame and loosely install bolts.
2. Align cargo box to cab.
3. **Torque** cargo box hold down bolts to 80 Nm. (59 ft. lbs.).
4. If removed, install tail lamp units and wire harness to cargo box.

5. Connect tail lamp wire harness to underbody wire harness.
6. If removed, install tailgate as outlined in [Tailgate](#).
7. If removed, install rear bumper as outlined in [Rear Bumper](#).
8. Connect fuel filler neck at fuel tank.
9. Connect battery ground cable(s).

Fig. 1 Cargo box removal

