



MATERIALS – (I HAD ALL THIS LYING AROUND SO USED WHAT IS SHOWN.

- 3 @ 2"x4"x96"
- 4 @ 1.25" STEEL ANGLE BRACKETS w 1.25" SCREWS. EXTRA SUPPORT FOR THE 6.5" PIECES.
- 16 @ 3" WOOD SCREWS. (I USED SOME DECK SCREWS)
- WOOD GLUE
- PAINT. (I HAD SOME ROCKER PANEL SPRAY PAINT. GOES ON FAST, THICK IN ONE COAT. USE ANY TYPE OF PAINT.)

2"x4" CUTS:

- 3 @ 31" LONG (ENSURE YOUR TANKS w VALVES WILL FIT THIS LENGTH)
- 1 @ 44.5" LONG
- 1 @ 49" LONG
- 2 @ 6.5" LONG

BUILD IT:

1. FASTEN THE BOARDS TOGETHER WITH GLUE AND 2 SCREWS AT EACH JOINT
2. ATTACH ANGLE BRACKETS ON THE 6.5" BOARDS.
3. SPRAY PAINT AND LET DRY.
4. DROP IN THE TRUCK BED.