

Jeep JL Transmission Shifter Adapter Installation Instructions:

1. Engage parking brake.
2. Pull factory shift knob upward to remove. A pry tool and hammer may be helpful.
3. There is a spring under the factory knob. After the factory knob is removed, keep the spring on the shifter.
4. Install the JL Transmission Shifter Adapter onto the shifter (over the spring).
5. Position the JL Transmission Shifter Adapter so that the set screws are aligned with one set screw centered on the flat area of the shifter. While pushing down on JL Transmission Shifter Adapter tighten both set screws.
6. Thread jam nut all the way down onto JL Transmission Shifter Adapter.
7. Thread shift knob onto JL Transmission Shifter Adapter until it touches jam nut.
8. Turn knob counter-clockwise until graphics are in desired position.
9. Turn jam nut counter-clockwise until it is tight against bottom of shift knob.
10. Check to make sure that the reverse lockout mechanism can easily engage to put the vehicle into reverse gear. If you cannot shift into reverse, loosen the two set screws and slightly raise the position of the JL Transmission Shifter Adapter. Then tighten the two set screws and check to make sure that the reverse lockout mechanism can be engaged to put the vehicle into reverse gear.

Contact Speed Dawg LLC with any technical questions toll free 1-866-906-7801 or 1-717-741-2665.

